

# LynTec AC Power Sequencing Products

A composite document of Brochures • Installation Instructions • AppNotes

Document Description	Document Part No.	Page
	(last 2 numbers [-xx] = revision, .x = page)	



## General Operators Instructions (all Sequencing Systems)

[Click to download individual document](#)

Operator's Instructions .....	139-0139-xx.....	<a href="#">02</a>
-------------------------------	------------------	--------------------

## Wiring Diagrams and accessories for all LynTec sequencers

Multiple Sequencer Hookup Diagram.....	139-0252-xx.2 .....	<a href="#">03</a>
Enlarged Daisy-Chain Hookup Diagram .....	139-0252-xx.3 .....	<a href="#">04</a>
Series - Parallel Hookup Diagram .....	139-0277-xx .....	<a href="#">05</a>
Emergency Shut Down & ZipOff (PANIC) switch .....	139-0256-xx.1 .....	<a href="#">06</a>
SS-2 & ZOS-5K Switch Set wiring & mechanical.....	139-0256-xx.2 .....	<a href="#">07</a>
PV-110 Power Voucher Brochure... <i>Not for new designs - Discontinued 5/05</i> .....	139-0113-xx .....	<a href="#">08</a>

## PDS-10 series (Latching Relay Sequencer, 4 to 10 circuits)

How It Works .....	139-0512-xx.1 .....	<a href="#">9</a>
Interior and Wiring.....	139-0512-xx.2 .....	<a href="#">10</a>
PDS-10 Mechanical Outline .....	139-0512-xx.3 .....	<a href="#">11</a>
PDS-10 Specifications .....	139-0512-xx.4.....	<a href="#">12</a>

## Modular Sequencing Systems — Square D panels using motorized circuit breakers

**MSLC** series **Sequencing Load Centers** — Cabinets hold 26, 29 or 41 breakers — Sequencer/s control 12, 24, 36 or 48 motorized breakers (Replaces **SLC** series - See [LynTec.com](#) for Discontinued product archive). and

**MSP** series **Sequencing Panelboards** — Cabinet holds 41 breakers — Sequencer/s control 12, 24, 36, 48 or 60 motorized breakers (Replaces **SP** series - See [LynTec.com](#) for Discontinued product archive).

All Panel Brochure — How it works.....	139-0357-xx.1 .....	<a href="#">13</a>
Available Models .....	139-0357-xx.2 .....	<a href="#">14</a>
Load Center Main Breakers, Q Frame .....	139-0343-xx .....	<a href="#">15</a>
Panelboard Main Breakers, H & J Frame.....	139-0394-xx .....	<a href="#">16</a>
Series Ratings.....	139-0407-xx .....	<a href="#">17</a>
Typical Panel schedule — others @ <a href="#">LynTec.com</a> .....	139-0357-xx.3 .....	<a href="#">18</a>
Control system and Panelboard photos .....	139-0357-xx.4-5 .....	<a href="#">19-20</a>
Specifier's Guide — Part Number Selector .....	139-0357-xx.6 .....	<a href="#">21</a>
Motorized Breakers — Cutaway photo & model numbers.....	139-0357-xx.7 .....	<a href="#">22</a>
Modular Sequencer Specifications.....	139-0357-xx.8 .....	<a href="#">23</a>
Architect's & Engineer's Specifications — Load Centers .....	139-0345-xx .....	<a href="#">24</a>
Architect's & Engineer's Specifications — Panelboards.....	139-0339-xx .....	<a href="#">25</a>
MRTS Series — Raintight — Sequences any Square D QO panel	139-0312-xx .....	<a href="#">26</a>
Modular Sequencer Timing diagram .....	139-0266-xx .....	<a href="#">27</a>

## Motorized Circuit Breakers

Motorized Breaker Specifications & Emergency Actuation .....	139-0216-xx .....	<a href="#">28-30</a>
Warranty Statement .....	139-0187-xx .....	<a href="#">31</a>
Job List.....	139-0163-xx .....	<a href="#">32</a>

## Application Note Index — [links to AppNotes](#)

AppNotes for Modular sequencing systems.....	139-0362-xx .....	<a href="#">33</a>
--	-------------------	--------------------

